

## ESTELLE 105/120/130 – RAPID 120/130/136

### BRAKE SYSTEM BLEEDING

Raise the vehicle to a workable height and release the handbrake.  
For 4 piston calliper brakes, remove the front wheels.

Starting with the N/S/R wheel, bleed the brakes in the order shown below for the given number of pedal depressions/volume of fluid, or until all old fluid and/or air is expelled.

### 2 PISTON BRAKE SYSTEM BLEEDING

N/S/R	15	PEDAL DEPRESSIONS
O/S/R	5	PEDAL DEPRESSIONS
N/S/F	15	PEDAL DEPRESSIONS
O/S/F	10	PEDAL DEPRESSIONS

### 4 PISTON BRAKE SYSTEM BLEEDING

N/S/R	15	PEDAL DEPRESSIONS
O/S/R	5	PEDAL DEPRESSIONS
N/S/F INNER	15	PEDAL DEPRESSIONS
N/S/F OUTER	2	PEDAL DEPRESSIONS
N/S/F TOP	15	PEDAL DEPRESSIONS
O/S/F INNER	10	PEDAL DEPRESSIONS
O/S/F OUTER	2	PEDAL DEPRESSIONS
O/S/F TOP	10	PEDAL DEPRESSIONS

### FINALLY

Ensure that all bleed nipples re tight and caps refitted.  
Apply pedal pressure to the system and check for leaks. Check for fluid spillage and wipe clean as necessary.